

38 845 LS0 **SKATE COSMOPOLITAN FLUSH PLATE**

SPARE PARTS, October 2009 – now

1: Cover plate with push button (Spare part-nr. 42369LS0)

